



## POWER CONNECTION INSTRUCTIONS

MOBILE 0400 927 510  
EMAIL: POWMARINA@GMAIL.COM  
WEB: WWW.PRINCEOFWALESBAYMARINA.COM.AU  
20 BENDER DRIVE, PRINCE OF WALES BAY TAS 7009

---

**The marina provides power for use on your vessel and outlined below are notes and requirements in relation to this connection:**

The low voltage electrical supply at this marina is at 240V, 50Hz supplied by socket outlets which will accommodate a standard 15A plug.

Precautions should be taken to prevent the supply lead from sagging or falling into the water.

It is dangerous & illegal for unskilled persons to attempt repairs or alterations.

**Your electrical supply lead should comply with the following:**

The current rating of the flexible cord shall not be less than 15 amps.

Plugs & sockets shall be rated at not less than 15 amps

All power cords must be tagged by an appropriately qualified person

All components shall be in good condition

We can assist you with reference to suitably qualified tradesman if you require any electrical works undertaken on your vessel.

Under no circumstances will the Marina accept responsibility for damage by connection to its low-voltage AC power distribution system